



Size: 8.25" x 5.875"

Color: Black




nickelodeon

1. Remove tab and throw away.




2. Push middle blade all the way down into the handles for "Conceal" mode.

3. Push both side blades on each Sai backwards and hold them in place.




4. Connect both Sais to each other and twist to conceal and securely lock into place.



NINJA REVEAL RAPHAEL'S SAIS

Reveal Sai Mode



Ages 4 and up
Asst. #83520
Item #83524



©2023 Paramount Pictures. All Rights Reserved. Teenage Mutant Ninja Turtles and all related titles, logos and characters are trademarks of Viacom International Inc.
©2023 Playmates. Playmates International Company Ltd.
23/F, The Toy House, 100 Canton Road, TST, Kowloon, Hong Kong. PRINTED IN CHINA.
Please keep all relative information for further reference.

For more detailed instruction information
visit www.Playmatestoys.com

| | |
|---------------------------------|--|
| Distributor - US Market Only | Playmates Toys Inc. 909 N. Pacific Coast Highway, Ste 800 El Segundo, CA 90245 Email: toys@playmatestoys.com |
|---------------------------------|--|